

Ultimaker Support › 3D Printers › Ultimaker S5 › Maintenance

Lubricate the Ultimaker S5's Z screw of the Z motor

January 30, 2020 08:28

The lead screw is connected to the Z motor and controls the movements of the Z stage. To ensure smooth movement of the Z stage, it is recommended to periodically apply grease to the lead screw.

Over time, grease may need to be reapplied to maintain consistent and accurate movement of the Z stage. A tube of grease is included in the accessory box of your Ultimaker S5.

1. Make sure that the build plate is positioned at the bottom of the Ultimaker S5
2. Apply a small amount of grease to the lead screw of the Z motor
3. In the Ultimaker menu, go to Configuration > Build plate
4. Select *Raise* and then *Lower* to move the build plate up and down to evenly distribute the grease

Note: Only use the grease on the lead screw of the Z motor.

Ask our community of experts

[Go to our community](#)



© Ultimaker Support



Was this article helpful?

  **Articles in this section**

1 out of 1 found this helpful

> Maintenance schedule of the Ultimaker S5

> Update the Ultimaker S5 firmware

Comments

> Ultimaker S5 firmware release notes

0 comments

> Firmware 6.0 for the Ultimaker S-line

> Material handling and storage for the Ultimaker S5

> Cleaning the Ultimaker S5

Article is closed for comments.

> Lubricate the Ultimaker S5 axles

> Check for play on the Ultimaker S5 axles

> Check the tension of Ultimaker S5 short belts

> Check for debris in the Ultimaker S5's front fan of the print head

[See more](#)

Recently viewed articles

- › How to perform a hot and cold pull
- › Clean the feeders on the Ultimaker S5
- › Check the quality of the Ultimaker S5 nozzle cover
- › Check for debris in the Ultimaker S5's front fan of the print head
- › Check the tension of Ultimaker S5 short belts