

Ultimaker Support › 3D Printers › Ultimaker S5 › Maintenance

# Lubricate the Ultimaker S5 door hinges

January 30, 2020 09:30

To make sure the glass doors will open and close smoothly, the hinges of the glass doors have to be lubricated once a year. This can be done by putting a small drop of oil in the top hole of each hinge.



Ask our community of experts

Go to our community



© Ultimaker Support

0 comments

---

Article is closed for comments.

---

## Articles in this section

- › Maintenance schedule of the Ultimaker S5
- › Update the Ultimaker S5 firmware
- › Ultimaker S5 firmware release notes
- › Firmware 6.0 for the Ultimaker S-line
- › Material handling and storage for the Ultimaker S5
- › Cleaning the Ultimaker S5
- › Lubricate the Ultimaker S5 axles
- › Check for play on the Ultimaker S5 axles
- › Check the tension of Ultimaker S5 short belts
- › Check for debris in the Ultimaker S5's front fan of the print head

[See more](#)

## Recently viewed articles

- › Clean the system fans of the Ultimaker S5
- › Lubricate the Ultimaker S5 feeder gear
- › Replace the Ultimaker S5 Bowden tubes
- › Lubricate the Ultimaker S5's Z screw of the Z motor
- › How to perform a hot and cold pull

