

Ultimaker Support › 3D Printers › Ultimaker 2 Extended › Maintenance

Lubricating the Ultimaker 2 Extended axles

February 18, 2020 09:27

To maintain your Ultimaker 2 Extended correctly and keep it running smoothly it is recommended to lubricate the axles once in a while.

X/Y axles

When you notice small ridges on the surfaces of your 3D printed objects or feel that the X and Y axles are dry it is advised to put a single drop of sewing machine oil onto the X and Y axles. This will help your Ultimaker 2 Extended running smoothly. Sewing machine oil is not included in the Ultimaker 2 Extended package, but we highly recommend to only use this for lubricating the X and Y axles.

Caution: Don't use WD40 as this will affect the coating that is on the axles. We advise to only use sewing machine oil for oiling the axles.

Z trapezoidal leadscrew

Once every half year the Z trapezoidal leadscrew has to be lubricated with Magnalube. This is the green grease that was delivered with your Ultimaker 2 Extended. Make sure to spread 10 drops of grease over the entire threaded rod. With your next print the Ultimaker 2 Extended will lubricate the axis itself by moving up and down.

Ask our community of experts

[Go to our community](#)



© Ultimaker Support

Was this article helpful?



0 out of 0 found this helpful

Comments

0 comments

Articles in this section

› [Atomic method for the Ultimaker 2 Extended](#)
Article is closed for comments.

› [Lubricating the Ultimaker 2 Extended axles](#)

› [The Ultimaker 2 Extended feeder](#)

› [Cleaning the glass plate of the Ultimaker 2 Extended](#)

Recently viewed articles

› [Cleaning the glass plate of the Ultimaker 2 Extended](#)

› [The Ultimaker 2 Extended user manual](#)

› [Clean the feeders on the Ultimaker 3](#)

› [Replace the Bowden tubes on the Ultimaker 3](#)

› [Lubricate the lead screw of the Z motor on the Ultimaker 3](#)