

Ultimaker Support › 3D Printers › Ultimaker 2 Extended › Maintenance

The Ultimaker 2 Extended feeder

February 18, 2020 09:24

Using the feeder in the right way and keeping it clean is important for a good extrusion. A few tips are described below.

Tension

In order to guide the filament properly through the feeder into the Bowden tube and print head, it's important that the tension on the feeder is set correctly. If the tension is too high, it means that the knurled wheel of the feeder will dig into the filament, through which it flattens or - even worse - completely gets stuck. This is what we call grinding.

To prevent grinding of the filament it is therefore important to set the tension on the feeder as loose as possible, meaning that the white insert clip should be completely at the top. You can achieve this by inserting one of the hex keys in the hole on top of the feeder and turning it clockwise.

Cleaning

After a lot of printing, the knurled wheel in the material feeder can accumulate small plastic particles. You can clean this by blowing air on the knurled wheel or using a simple brush. It is also recommended to clean the feeder when you notice grinding of the filament.

Ask our community of experts

Go to our community



© Ultimaker Support

0 comments

Article is closed for comments.

Articles in this section

- › Atomic method for the Ultimaker 2 Extended
- › Lubricating the Ultimaker 2 Extended axles
- › The Ultimaker 2 Extended feeder
- › Cleaning the glass plate of the Ultimaker 2 Extended

Recently viewed articles

- › Lubricating the Ultimaker 2 Extended axles
- › Cleaning the glass plate of the Ultimaker 2 Extended
- › The Ultimaker 2 Extended user manual
- › Clean the feeders on the Ultimaker 3
- › Replace the Bowden tubes on the Ultimaker 3