



# Top never change

1-12 - Normal  
13/14 - Half-Normal  
15-24 - Through




# Back never change




# Front The user interface

To use the Firewire Interface, just remove all cables from the front.



To use Airplay, patch your stereo pairs on speakers. AS 1 and room audio are always patched together.



- 1 - 16
- 2 - 18
- 3 - 13
- 4 - 17
- 5 - 14
- 6 - 19
- 7 - 15
- 8 - 20